



Thank you for choosing a BATSTAR product!


Please briefly read this instruction manual before using this product.

Technical Specification	
IP Class:	IP55
Operating Temperature:	-20 °C ~ 60 °C (-4 °F ~ 140 °F)
Storage Temperature:	-30 °C ~ 70 °C (-22 °F ~ 158 °F)

Dimension:	Ø 15 mm
Impedance:	32 Ω ⁺ /- 15 %
Power Rating:	Normal 0.03 W / Max. 0.05 W

Using the Earphone Acoustic Tube

Put the ear-bud of the Earphone Acoustic Tube "Silver" smoothly into your ear (1) and make it durable, guiding the transparent acoustic tube along your back-ear and then behind the head to the other side of your head. (2)



Then stabilize it with the clip on your lapel or collar (3). It can be worn on the right or on the left ear. Before the first use of the Earphone Acoustic Tube "Silver", find out which ear-bud (small / large) fits your ear best.

Comfortable Cleaning

To clean the Earphone Acoustic Tube "Silver", disassemble the earphone into its separate parts. (Please see "Build-Up" of the earphone on the right.) Then you can clean ear-buds, connecting piece and the transparent acoustic tube in warm water. You can clean the transducer and cable carefully with a dry and soft cloth. DO NOT put the transducer or cable in any liquids!

Build-Up

You can disassemble the Earphone Acoustic Tube "Silver" into the following parts:

(a) Ear-Bud (Small or Large)

Specification of Speaker

- (b) Connecting Piece 90 Degree
- (c) Acoustic Tube
- (d) Sound Transducer
- (e) Replacement Cable

